

USER MANUAL

WA-6505A

Distribution Mixer Amplifier





1. Security Precautions

- ⦿ Carefully to **READ** the instruction in this manual before use.
- ⦿ Certainly to **OBSERVE the INSTRUCTION** in this manual regard convention of safety symbols and messages
- ⦿ Please **KEEP** this user **MANUAL** nearby for anytime reference.

Safety symbol and Message Conventions

Below-described safety symbol and messages are to prevent bodily injury and property damage. Before operating the amplifier, read this manual first so you completely knowing the potential safety hazard and understanding the meaning of the safety symbols and messages.

 WARNING	Indicates a potentially hazardous situation, which, if mishandled, could result in death or serious body injury, and/or property damage.
 CAUTION	Indicates a potentially hazardous situation, which, if mishandled, could result in moderate or minor body injury, and/or property damage.



■ When Installing the Amplifier

- **DO NOT** installing or mounting the amplifier in unstable locations, such as on the rickety table or the slanted surface. It may result in the amplifier falling down and causing body injury and/or property damage.
- **Be sure to ground** to the safety ground (earth) terminal to avoid electric shock. Never to ground to a gas pipe for tragic disaster may occur.
- Use the amplifier only with the voltage specified on the amplifier. Using the voltage higher than specified may cause fire or electric shock.
- **DO NOT** cut, twist, damage, nor modify the power supply cord. In addition, avoid using the power cord close to heaters, and don't place heavy object, including the amplifier itself, on the power cord, for it may cause fire or electric shock.
- **DO NOT** expose the amplifier to rain or the environment where it may be splashed by water or other liquids, for doing so, it may cause fire or electric shock.

■ When using the Amplifier

- When found following irregular situation during amplifier is in use, immediately switch off the power, disconnect the power supply plug from the AC outlet. Don't try to operate the amplifier again. Contact your local dealer to check the amplifier.
 - ✓ The amplifier falls.
 - ✓ Amplifier is malfunction.
 - ✓ Water or any metallic object gets into the amplifier.
 - ✓ The smoke or strange smell coming from the amplifier.
 - ✓ The power supply cord is damaged, such as exposure of the core, disconnection etc..
- **DO NOT** put cups, bowls, or other containers with liquid or metallic object in it on the top of the amplifier. If they spill accidentally into the amplifier, it may result in fire or electric shock.
- **DO NOT** touch the power supply plug during thundering and lightning, for it may result in electric shock.
- **DO NOT** insert or drop the metallic objects or flammable materials into the ventilation slots of the amplifier, for it may result in fire or electric shock.
- **DO NOT** open nor remove the amplifier cover to prevent fire or electric shock, for there are high voltage components inside the amplifier.



■ When Installing the Amplifier

- **DO NOT** remove nor plug in the power supply plug with wet hands, for it may cause electric shock.
- When unplug the power supply cord, be sure to grasp the power supply plug. **DO NOT** pull on the cord itself. Operating the amplifier with damaged power supply cord may cause fire or electric shock.
- **Avoid** installing the amplifier in humid or dusty places, the area exposed to the direct sunlight, locations generating smoke or steam, or the spot near the heaters. It may result in fire or electric shock.
- When moving the amplifier, be sure to remove its power supply cord from the wall outlet. Moving the amplifier with the power cord connected to the outlet may cause damage to the power cord, and resulting in fire or electric shock. When removing the power cord, be sure to grasp its plug to pull.
- **DO NOT** block the ventilation slots of the amplifier chassis. It will cause the temperature rising and result in fire.

■ When Using the Amplifier

- Make sure that the volume control is turned to minimum position before power is switched on. Loud sound produced at high volume when power is switched on may impair hearing.
- **DO NOT** place heavy objects on the amplifier, for it may cause it fall and may result in body injury and/or property damage. Besides, the object itself may cause damaged or body injury.
- **DO NOT** operate the amplifier for the extended period of time with the sound distorting. It is an indication of malfunction, which can cause heat and result in fire.
- Switch the power off, and unplug the power supply plug from the AC outlet for safety purposes, when cleaning or leaving the amplifier unused for 7 days or more. Fire or electric shock may occur.
- If the dust accumulates on the power supply plug or in the wall AC outlet, fire may result in. Clean it periodically. In addition, make sure the plug is inserted in the wall outlet securely.
- Contact your local dealer to clean the dust, if the dust has accumulated in the amplifier for a long period of time. Dust accumulation may result in fire or damage.

2. Description

WA-6506A is the mixer amplifier designed for up to 5 channels (zones) application. Each channel output is 50W RMS. And each one has its own bass, treble, and level (volume) control. There are 6 input sources: Aux 1 ~ 4, and 2 "High Level" inputs. "High Level" input is for the connection from the output of other amplifier, no matter it is 8 ohm, 25V, or 70V.

The front MIC. 1 input has the voice priority function with level control. Each channel has one push switch to select to mute its own signal source or not.

To ensure the amplifier safety, it has speaker short, over temperature, and over load protection.


The output connection is 8 ohm, 25V, and 70V screw terminal.

It accepts AC 115V/230V 50/60 Hz and DC 24V input.

WA-6505A is the ideal mixer amplifier for multi-zone with multi sources.


3. Panel Description

FRONT PANEL DESCRIPTION



1. MIC. 1 Input	16. Channel 1 Volume Control
2. MIC. 1 Volume Control	17. Channel 2 Bass Control
3. Channel 1 Mute Priority Switch	18. Channel 2 Treble Control
4. Channel 1 Input Source Selection Switch	19. Channel 2 Volume Control
5. Channel 2 Mute Priority Switch	20. Channel 3 Bass Control
6. Channel 2 Input Source Selection Switch	21. Channel 3 Treble Control
7. Channel 3 Mute Priority Switch	22. Channel 3 Volume Control
8. Channel 3 Input Source Selection Switch	23. Channel 4 Bass Control
9. Channel 4 Mute Priority Switch	24. Channel 4 Treble Control
10. Channel 4 Input Source Selection Switch	25. Channel 4 Volume Control
11. Channel 5 Mute Priority Switch	26. Channel 5 Bass Control
12. Channel 5 Input Source Selection Switch	27. Channel 5 Treble Control
13. Power Switch	28. Channel 5 Volume Control
14. Channel 1 Bass Control	29. Power Indicator - LED
15. Channel 1 Treble Control	

REAR PANEL DESCRIPTION



1. AC Power Input Socket	8. Channel 1 Output Terminal
2. Earth Ground Connection Screw	9. "High Level" Input Terminal
3. AC Voltage (115V/230V) Selection Switch	10. Aux 2 ~ 4 Input (RCA Jack)
4. Channel 5 Output Terminal	11. Aux 1/MIC 2 Selection Switch
5. Channel 4 Output Terminal	12. Aux 1/MIC 2 Input
6. Channel 3 Output Terminal	13. AC Fuse
7. Channel 2 Output Terminal	14. DC Power Supply Terminals

4. Features

- Up to 5 channels (zone)
- 6 selectable input sources + MIC 1 (First Priority)
- 2 "High Level" input (included in 6 selectable input source).
- Bass, treble, and volume control for each channel
- Voice priority function on MIC. 1
- Over load, over temperature, and speaker short protection.
- 8 ohm, 25V, and 70V output
- AC and DC power in
- 2U height
- 19" rack or table mounted

5. Power Source

● AC Power Source

The supply transformer has been designed for use on either 115V or 230V, (50-60Hz), selected by a push switch on the rear panel. The amplifier is factory set at 230Vac mains voltage.

● DC Power Source


Battery Connection (24Vdc)

When using external batteries, ground the amplifier via the screw terminal. (Electrical stability of the system will be improved by providing a good earth ground.) When connecting batteries please ensure correct polarity.

6. Connection

● Microphone Connection

Mic1~2 inputs are unbalanced standard 1/4" Phone Jack.




Mute Function

Priority Microphone, Mic1 input has VOX priority over CH 1~5. Press the push switch of each channel on the front panel to mute the corresponding signal source.

Aux Connection (Input)

The equipment provides 4 auxiliary input which may be used for connecting other signal sources such as a Radio Tuner, CD or Cassette player. A slide switch is located near by AUX1/MIC 2 on the rear panel for selection of Mic2 or Aux1. Aux 2 ~ 4 inputs are a dual RCA jack and has a stereo to mono converter for each channel



RCA plug connector

● High Level Input Connection

The "High Level" terminal is for connecting the signal sources from other amplifier output, which is normally connected to the speaker.

● Output Connection

There are 5 output terminals on the rear panel. Each terminal has 3 speaker outputs: 8 ohm, 70V and 100V. Use only one of these outputs for connection.

7. Operation

After all connections are completed, turn the Input Source Selection Switch of each channel to set on the corresponding position for the signal source. If necessary, turn the bass, treble, and volume control to what you desire.

Before using the microphone 1 on the front panel to broadcast, make sure the level (volume) control of MIC 1 is at proper position (not at maximum position). Set the push switch of each channel to control the mute function of its own channel signal source. Switch-down is to mute signal source, only the voice from MIC 1 can be heard, while switch-up does not mute signal source, both voice from MIC 1 and channel signal can be heard. If necessary to adjust the volume further, turn the level control of MIC 1 and/or of Channel 1 ~ 5.

8. Technical Specification

Model	WA-6505A	
Type	Distribution Mixer Amplifier	
Supply	Mains Voltage	AC 115V/ 230V, 50 / 60Hz \pm 10% Switchable
	Battery Voltage	DC 24V (MAX 10% deviation)
Output Power:	50W x 5	
Total Harmonic Distortion	\leq 0.1% @ 1KHz, rated power	
Sensitivity	1/4" PHONE JACK (UNBALANCED) MIC 1~2 1 mV @ 600 ohm AUX 1 200mV @ 20K ohm RCA JACK (UNBALANCED) AUX 2 200mV @ 20K ohm AUX 3 200mV @ 20K ohm AUX 4 200smV @ 20K ohm SPEAKER JACK (UNBALANCED) HI LEVEL 100V @ 300 ohm	
Frequency Response	50Hz ~ 15KHz \pm 3dB	
Output	70V, 25V, 8 ohm; screw terminal	
Signal to noise ratio	< 70dB	
Damping Factor	>200	
Voice Priority Mute	MIC. 1	
Protection	Speaker Short Temperature Over Load	
AC power consumption	640W @ rated power	
DC power consumption	15A @ rated power	
Dimensions (H x W x D)mm	88 (H) x 425(W) x 345 (D) mm	
Weight	15 kgs	
Mounting	Free standing or 19" rack	

WARNING: THIS APPLIANCE MUST BE EARTHED

