
USER MANUAL

WA-648

BOOSTER AMPLIFIER






Weltron®

1. Security Precautions

- O Carefully to READ the instruction in this manual before use.
- Certainly to OBSERVE the INSTRUCTION in this manual regard convention of safety symbols and messages.
- Please KEEP this user MANUAL nearby for anytime reference.

Safety symbol and Message Conventions

Below-described safety symbol and messages are to prevent bodily injury and property damage. Before operating the amplifier, read this manual first so you completely knowing the potential safety hazard and understanding the meaning of the safety symbols and messages.





When Installing the Amplifier

- DO NOT installing or mounting the amplifier in unstable locations, such as on the rickety table or the slanted surface. It may result in the amplifier falling down and causing body injury and/or property damage.
- Be sure to ground to the safety ground (earth) terminal to avoid electric shock.
 Never to ground to a gas pipe for tragic disaster may occur.
- Use the amplifier only with the voltage specified on the amplifier. Using the voltage higher than specified may cause fire or electric shock.
- DO NOT cut, twist, damage, nor modify the power supply cord. In addition, avoid
 using the power cord close to heaters, and don't place heavy object, including the
 amplifier itself, on the power cord, for it may cause fire or electric shock.
- DO NOT expose the amplifier to rain or the environment where it may be splashed by water or other liquids, for doing so, it may cause fire or electric shock.

When Using the Amplifier

- Make sure that the volume control is turned to minimum position before power is switched on. Loud sound produced at high volume when power is switched on may impair hearing.
- DO NOT place heavy objects on the amplifier, for it may cause it fall and may result
 in body injury and/or property damage. Besides, the object itself may cause
 damaged or body injury.
- **DO NOT** operate the amplifier for the extended period of time with the sound distorting. It is an indication of malfunction, which can cause heat and result in fire.
- Switch the power off, and unplug the power supply plug from the AC outlet for safety purposes, when cleaning or leaving the amplifier unused for 7 days or more. Fire or electric shock may occur.
- If the dust accumulates on the power supply plug or in the wall AC outlet, fire may result in. Clean it periodically. In addition, make sure the plug is inserted in the wall outlet securely.
- Contact your local dealer to clean the dust, it the dust has accumulated in the amplifier for a long period of time. Dust accumulation may result in fire or damage.

2. Description

WA-648 is easy to use booster amplifier. It has one phone jack and one XLR jack as input; and the same as output. And there is one screw speaker output terminal for the direct connection to 8 ohm, or 25V, or 70V speaker.

There is only one set of LED as power on and level indicators on the front panel. On the rear panel the sensitivity selection switch is for the sensitivity 100mV or 1V selection. Beside the switch, there is one gain control for the input signal adjustment.

Besides 115 / 230V AC power source, WA-648 booster amplifier also accept DC 24V battery power source as backup power.

To ensure the amplifier working normally and safe operation, it has speaker short, over temperature, and overload protection function.


WA-648 series is simple and easy to use booster amplifier.

3.Front Panel



- 1. Power Switch
- 2. Power On Indicator LED
- 3. Level Indicator LED

4.Rear Panel



- 1. AC Power Input Socket
- 2. Earth Connection Screw
- 3. AC Voltage (115V/230V) Selection Switch
- 4. DC Power Supply Terminal
- 5. Speaker Output Terminal
- 6. Phone Output Jack
- 7. XLR Output Jack

- 8. Parallel/Mono Selection Switch
- 9. Sensitivity (100mV /1V) Selection Switch
- 10. Gain Control
- 11. XLR Input Jack
- 12. Phone Input Jack
- 13. AC Fuse

5. Features

- Easy to use booster Amplifier
- 8 ohm, 25V and 70V speaker output
- One XLR and Phone jack for input and output
- Sensitivity Selection Switch
- Overload, over temperature, and speaker short protection.
- AC or DC power in
- 3U height
- 19" rack or table mounted

6. Power Source

AC Power Source

The supply transformer has been designed for AC 115V / 230V (±10%) 50 /60 Hz.

DC Power Source

Battery Connection (24Vdc)

When using external batteries, ground the amplifier via the screw terminal. (Electrical stability of the system will be improved by providing a good earth ground.) When connecting batteries, please ensure correct polarity.

7. Connection

Input Connection

Connect signal source to input jack by using phone jack cable.

Output Connection

Connect output jack to other amplifier by using phone jack cable.

Speaker Output Connection

The speaker output screw terminal is on the rear panel. It can connect low impedance 8 ohm, or high-level 25V or 70V speaker. Use only one of these output connections for corresponding speaker.

Sensitivity Selection Switch

Put the switch on 100mV or 1V position for corresponding sensitivity of signal source from other device.

When using the Amplifier

- When found following irregular situation during amplifier is in use, immediately switch
 off the power, disconnect the power supply plug from the AC outlet. Don't try to
 operate the amplifier again. Contact your local dealer to check the amplifier.
 - ✓ The amplifier falls.
 - ✓ Amplifier is malfunction.
 - ✓ Water or any metallic object gets into the amplifier.
 - ✓ The smoke or strange smell coming from the amplifier.
 - The power supply cord is damaged, such as exposure of the core, disconnection etc.
 - DO NOT put cups, bowls, or other containers with liquid or metallic object in it on the top of the amplifier. If they spill accidentally into the amplifier, it may result in fire or electric shock.
 - DO NOT touch the power supply plug during thundering and lightning, for it may result in electric shock.
 - DO NOT insert or drop the metallic objects or flammable materials into the ventilation slots of the amplifier, for it may result in fire or electric shock.
 - DO NOT open nor remove the amplifier cover to prevent fire or electric shock, for there are high voltage components inside the amplifier.



When Installing the Amplifier

- DO NOT remove nor plug in the power supply plug with wet hands, for it may cause electric shock.
- When unplug the power supply cord, be sure to grasp the power supply plug.
 DO NOT pull on the cord itself. Operating the amplifier with damaged power supply cord may cause fire or electric shock.
- Avoid installing the amplifier in humid or dusty places, the area exposed to the direct sunlight, locations generating smoke or steam, or the spot near the heaters.
 It may result in fire or electric shock.
- When moving the amplifier, be sure to remove its power supply cord from the wall
 outlet. Moving the amplifier with the power cord connected to the outlet may
 cause damage to the power cord, and resulting in fire or electric shock. When
 removing the power cord, be sure to grasp its plug to pull.
- DO NOT Block the ventilation slots of the amplifier chassis. It will cause the temperature rising and result in fire.

8. Operation

After all connections are completed, turn on the power. If necessary, turn the level control of the source device to what you desire.

9. Specifications

Туре		Booster Amplifier
Model		WA-648
Output Power (RMS)		480W
Power Supply	Main Voltage	AC 115 / 230V 50/60Hz
	Battery Voltage	DC 24V
Total Harmonic Distortion		<= 1% @ 1KHz, rated power
Sensitivity		XLR, Phone Jack (Balanced) 1V, 100mV @ 10K ohm
Outputs		8Ω, 25V, 70V
Signal to Noise Ratio		86 dB
Indicator		Power On, Level
AC Power Consumption		1280W
DC Power Consumption		30A
Dimensions (mm)		132(H) x 425(W) x 355(D)
Weight		17 Kgs
Mounting options		Desktop or 19" rack

WARNING: THIS APPLIANCE MUST BE EARTHED

